

EROSION CONTROL

- Protect soil piles with an approved BMP method.
- Protect (on-site) storm drain inlets and around the project with an approved BMP.
- At the end of each work day, sweep or scrape up any soil that was tracked onto the road.
- By the end of the next work day after a storm, clean up any soil that may have been washed off-site.
- Inspect remove sediment deposits.
- Secure bags of cement after they are open. Be sure to keep windblown cement powder away from gutters, storm drains and runoff.
- Place concrete washout in an approved designated washout area.
- Concrete can be washed out in a secure plastic lined area.

Contact Information:

To report a spill during regular business hours Monday - Thursday 7AM - 6PM contact: Provo City Storm Water at 801-852-6700.

To report a spill after business hours contact Provo City Customer Service by dialing 311.

For general storm water program information contact the Storm Water Quality Program Manager at 801-852-6733, or check out our [website](#). Our offices are located at 1377 S 350 E, Provo.

For waste disposal questions contact: South Utah Valley Solid Waste District at 801 489 3027 or visit the following website: suvswd.org/what-to-do-with.

Anyone caught discharging anything but rain into the storm drain is subject to penalties and/or fines, plus the cost of clean up. Please help stop storm water pollution at the source.

